

Update V20 – V30

Do not perform this update without consulting Schüco!

Data transfer from V20

1. Copy machine directory from V20 to V30
 - a. Source directory of V20:
„C:\ProgramData\Schueco\CAM V20\Machines\AF500_Default“
 - b. Target directory of V30:
„C:\Schueco\CAM V30\Machines\AF500_Default“
2. Start CAM V30 and confirm error message with „SpindelquaderHSD“
3. Modify directorys of V30:
 - a. Data base
 - b. DXF
 - c. Tool-DXF
 - d. Job
 - e. Souce
 - f. Target
4. Restart CAM (no erros should occur)
5. Check tools in tool menu